

QUICK CONNECT GUIDE

HOW TO SET UP YOUR **FIBRE INTERNET** ONT & WI-FI G6 BEACON

WI-FI NETWORK CREDENTIALS:

Your Network name is Execulink plus the last 4 digits of the serial number. Your Network password is located on the bottom of the Router, labeled WiFi Key.

NEED HELP? Visit us at execulink.ca/support
For Wi-Fi troubleshooting try our app, Execulink Helps.

STEP 1: DOUBLE CHECK

Make sure you have the following components in your High Speed Internet package.

Optical Network Terminal (ONT) & Power Adapter



Premium Wi-Fi G6 Beacon & Power Adapter



Ethernet Cable

Colour may not be exactly as shown.



STEP 2: CONNECT BEACON & ONT

1. Make sure all equipment is unplugged.
2. Connect one end of the Ethernet cable to the Ethernet port on the ONT.
3. Connect the other end of the Ethernet cable to the blue WAN port on the Wi-Fi G6 Beacon.




Beacon

ONT

STEP 3: POWER UP ONT & BEACON

1. Plug in the ONT's power adapter into the Power port, and the other end into a wall outlet.
2. Plug in the Beacon's power adapter and push the ON/OFF switch to ON and allow the Beacon to boot up.




Beacon

ONT

STEP 4: FINAL SETUP

After several minutes the LED on the front will be solid blue-green to indicate that it is ready.

To customize your wireless settings including password, network names and more, please download the Nokia Wi-Fi App or visit execulink.ca/myexeculink.



ONT




Beacon

OPTIONAL: DOWNLOAD NOKIA WI-FI APP

Using your mobile device, go to the Google Play or App Store to download the Nokia WiFi app on your Android or iOS device.

The Nokia WiFi app will allow you to manage all of your Wi-Fi devices and settings such as your, password, SSID, guest network, parental controls, and much more.

In the Nokia app, choose the "Get Started" option to begin setup.



NEED HELP?

CALL 1.877.393.2854
VISIT SUPPORT.EXECULINK.CA

QUICK CONNECT GUIDE


How to set up your FIBRE VOIP PHONE

Only complete these steps after establishing an Internet connection and after your Phone service has been activated. Your activation date is provided by an Execulink representative.

NEED HELP? Visit us at execulink.ca/support
Or call us 24/7 at 1.877.393.2854

STEP 2: CONNECT PHONE

1. Plug a supplied Ethernet cable into the yellow LAN1 port of the Wi-Fi G6 Beacon.
2. Plug the other end of the Ethernet cable into the Network or Internet port of the VoIP ATA.
3. Plug in the ATA's power adapter into the back of the ATA and the other end into a wall outlet.



VoIP ATA

Please note: It can take up to 10 minutes to sync these devices.

STEP 1: CHECK HARDWARE

Make sure you have the following components in your Fibre Phone package:

VoIP ATA & Power Adapter




Ethernet Cable




STEP 3: TEST YOUR PHONE

1. Plug your telephone cord into the Phone 1 port on the back of the ATA and the other end into your phone.
2. If you use a cordless telephone, please ensure the cordless base station's power adapter is also plugged into a working electrical outlet.
3. The phone indicator light on top of the ATA should be lighting up green. Pick up your phone and check for a dial tone and make an outgoing call to test.
4. a) If you are keeping your phone number, call our Customer Care team at 1-877-393-2854 to port your number. **If there is no answer**, please leave a voicemail message with your name, phone number and tell us if the ATA is connected. An Execulink representative will call you back within 1 business day at which point your phone will be fully operational.
b) If you are using a new phone number, congratulations— your new phone is ready for use!



VoIP ATA

FINAL INTERNET & PHONE SETUP:



VoIP ATA

Beacon

ONT